








ITEM# 2155/2155-15
MESH BACKPACK TENT
ASSEMBLY INSTRUCTION

6 FT 6 IN (L) x 5 FT 6 IN (W) x 43 IN (H)
2M (L) x 1.7M (W) x 110CM (H)



| ITEM | PART | QTY (PCS) | PART NAME |
|------|---|-----------|-------------|
| A |  | 2 | TENT POLES |
| B |  | 1 | TENT |
| C |  | 1 | RAIN FLY |
| D |  | 7 | STAKE |
| E |  | 1 | STORAGE BAG |

WARNING:

KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC
This tent meets the flammability requirements of CPAI-84. The fabric may burn if left in continuous contact with any flame source. The application of any foreign substance to the tent fabric may render the flame-resistant properties ineffective

This tent should be secured to the ground with stakes and guy lines.

ASSEMBLY INSTRUCTIONS

IMPORTANT: DO NOT USE EXCESSIVE FORCE DURING ANY PART OF SET-UP

| | |
|---|--|
| 1 | Remove the tent, rain fly, and tent poles from the tent storage bag. |
| 2 | Carefully assemble the tent poles. |
| 3 | Spread the tent out on a flat surface with the tent floor against the ground. |
| 4 | Straighten poles. Lay first pole on top of the tent diagonally. |
| 5 | Insert pins from tent corners into pole end ferrules. |
| 6 | Fasten poles to body of tent with clips along seam. Repeat Step 5 with other pole. |
| 7 | Pull fly over tent and hook corner bungees of rain fly to the fly loops along tent corner seams. |

If you need any help setting up your new tent, feel free to contact us.

PHONE:
1 (800) 421-6131

CHAT:
www.stansport.com

TWITTER:
[@stansport](https://twitter.com/stansport)



Stansport, Inc.
2801 E. 12th Street
Los Angeles, CA 90023