



## STEP 6




## PARTS




## NOTE

Lock **Left Side of Body (2)** and **Right Side of Body (3)** by rotating the lock tabs on the back of the set.

## STEP 7



## PARTS




## NOTE


Remove the battery cover and install the appropriate batteries. Secure the battery compartment door for players safety.

Requires 3 "AAA" size batteries (not included). Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.

## STEP 8



## PARTS



## NOTE

Next, install the **Electronic Scoring Unit (6)** by aligning the male plug that's on part 1 to the female plug on the scoring unit. Finally, raise part 6 up to the top of part 1 and slide it into the built-in tabs on part 1.

Note: make sure that you take your time aligning the plug to the scoring unit to prevent damage to the item.

# YOU ARE NOW READY TO PLAY!

## GAME INSTRUCTIONS

### RULES:

This game can be played with as many people as you want. Each player will play one round for 30 seconds and try and score as many points as they can. At the end of their turn, the scoring unit will display how many points they scored. After all players have gone, the one with the highest score at the end wins.

### SCORING:

Once the game clock starts, the player up will roll their ball towards the launch ramp. Players can choose to try and aim at any point value. The lower the point value, the easier it will be to score more points.

Made In China  
Franklin Sports Inc.  
Stoughton, MA 02072

**Franklin**

For replacement parts:  
Visit: [www.franklinsports.com/54239/54239P2](http://www.franklinsports.com/54239/54239P2)  
Email: [parts@franklinsports.com](mailto:parts@franklinsports.com)  
Call: 1-800-225-8649

**Franklin**



# WHIRL BALL

ITEM NUMBER: **54239** **54239P2**









For all your replacement part needs, please visit:  
[www.franklinsports.com/54239/54239P2](http://www.franklinsports.com/54239/54239P2)



Ages 6+

NOTE: PRINT FRONT TO BACK

PARTS LIST


<div>1</div> <div></div> <div>QTY x1</div> <div>Whirl Ball Main Body Rep. Part: 54239-R1</div>	<div>2</div> <div></div> <div>QTY x1</div> <div>Left Side of Body Rep. Part: 54239-R2</div>	<div>3</div> <div></div> <div>QTY x1</div> <div>Right Side of Body Rep. Part: 54239-R3</div>	<div>4</div> <div></div> <div>QTY x1</div> <div>Launch Ramp Rep. Part: 55120-R4</div>
<div>5</div> <div></div> <div>QTY x1</div> <div>Return Ramp Rep. Part: 55120-R5</div>	<div>6</div> <div></div> <div>QTY x1</div> <div>Electronic Scoring Unit Rep. Part: 55120-R6</div>	<div>7</div> <div></div> <div>QTY x2</div> <div>Roller Sports Balls Rep. Part: 55120-R7</div>	<div>8</div> <div></div> <div>QTY x4</div> <div>Arrow Stickers Rep. Part: 54239-R8</div>

ASSEMBLY INSTRUCTIONS


GENERAL NOTES


Start by laying out all the pieces in a clean flat location.

STEP 1



PARTS


 x1

 x4


NOTE


Start by applying the **Arrow Stickers (8)** to the **Launch Ramp (4)**.

STEP 2



PARTS


 x1

 x1


NOTE


Join the **Launch Ramp (4)** and **Return Ramp (5)** together. Insert the tabs of part 5 into the side of part 4, then slide down to lock in place.

STEP 3



PARTS


 x1

 x1


NOTE

Insert the parts from step one into the bottom of part **Main Body (1)** until part 4 is flush with the bottom of part 1.

STEP 4




PARTS

 x1


NOTE


Extend the legs of the **Main Body (1)** as shown.


STEP 5



PARTS

 x1

 x1

 x1

NOTE

When looking at the item, align and slide on **Left Side of Body (2)** on the left and **Right Side of Body (3)** on the right of the item.