


ASSEMBLY, MAINTENANCE, & **USER MANUAL**

MODEL #SSGM100



WARNING

Read all precautions and instructions in this manual before using this equipment. Save this manual for future reference.



Skywalker Holdings LLC
P.O. Box 574, Brigham City, UT 84302

TABLE OF CONTENTS

Part List.....	3
Part Identification.....	4-5
Exploded Drawing.....	6
Assembly.....	7-10
Limited Warranty.....	11



STOP EVERYTHING YOU'RE DOING AND REGISTER YOUR PRODUCT

Find our warranty registration online by typing in: www.skywalkertrampolines.com/registration/

You'll need to have the following information handy:

- Name
- Address
- Phone number
- Date of purchase
- Email address
- Product model number
- Product serial number
- Retailer the product was purchased from

HEY WE'VE GOT SOMETHING REALLY IMPORTANT TO SAY

Check us out online! We've got **assembly videos** (for those of you who prefer movies over books), **FAQs** (so you know you're not the only one who needs help), fascinating **blog posts (5 Tips to Keep Your Kids Active)**, and most importantly, find us on social media! Because we want to be your friend. **We'd love to see how you are using our products!**

Website: skywalkertrampolines.com

Facebook: facebook.com/skywalkertrampolines

YouTube: youtube.com/c/SkywalkerTrampolines

Pinterest: pinterest.com/swtrampolines

Twitter: twitter.com/swtrampolines

Instagram: instagram.com/skywalker_trampolines



WARNING

CHOKING HAZARD- Small parts not for children under 3 years.



WARNING

Adult assembly required.

PART LIST

Key No.	Qty.	Description
1	2	Upper Upright Pole
2	2	Lower Upright Pole
3	1	Volleyball Net
4	2	Upright Ground Stake
5	6	Tensioning Device
6	6	Ground Stake
7	4	Metal clip
8	6	Guide Line
9	10	Lug Bolt
10	20	M6 Washer
11	10	M6 Locknut
12	1	Wrench
13	1	Bag
14	1	Volleyball
15	1	Pump
16	2	Plastic strap

ORDERING REPLACEMENT PARTS

We get it, sometimes things happen, but the fun shouldn't stop just because you need a new bolt or screw. To order replacement parts, check out our website at: www.skywalkertrampolines.com or call our toll-free Customer Care Hot-line at **1-866-603-Jump (5867)**, Monday - Thursday 8 a.m. to 5 p.m., Friday 8 a.m. to 3 p.m. (excluding holidays).

Our customer service team will ask you a few questions in order to get the replacement part sent out as soon as possible. We're not trying to complicate your life, we promise.

When calling, make sure to have the following information ready:


- The model # of the product (see the front cover of this manual)
- The key # and description of the part (see the part list above)
- The quantity of parts needed (only you know the answer to that one)

BEFORE YOU BEGIN

Thanks for choosing Skywalker Sports! We're just as excited as you are to help your family live an active (but most importantly **FUN**) lifestyle. This model is one of our favorites, and we're confident you'll love it too. We want to make things easier for you, so we have listed all the important information that you (and your little outdoor adventurers) need to know. Make sure you brush up on the warnings, instructions, assembly, maintenance, and use of your new product, because there will be a pop quiz at the end (Okay, not **REALLY**, but if you're still reading this, props to you! You're awesome.).


PART IDENTIFICATION

Before you begin, take a look at the drawings below to make sure you have all the parts! The numbers in the squares to the left (key numbers) will help you identify the parts during assembly.




1

Upper Upright Pole **(x2)**




2

Lower Upright Pole **(x2)**



3

Volleyball Net **(x1)**




4

Upright Ground Stake **(x2)**




5

Tensioning Device **(x6)**



6

Ground Stake **(x6)**




7

Metal Clip **(x4)**
Pre-installed




8

Guide Line **(x6)**




9

Lug Bolt **(x10)**



10

M6 Washer **(x20)**




11

M6 Locknut **(x10)**



12

Wrench **(x1)**



13 Bag (x1)



14 Volleyball (x1)




15 Pump (x1)



16 Plastic strap (x2)

EXPLODED DRAWING



ASSEMBLY

READ THIS BEFORE YOU BEGIN

- We've provided some tools to help with assembly, but you're more than welcome to use your own
- The assembly steps refer to parts by their descriptions and key numbers (see the part list on page 3)
- The assembly steps are written in a specific order, and if you don't follow them exactly, you may end up having to start all over again
- Most importantly, this may not be the easiest thing you've ever done, but it will be **worth it**. Trust us


If you're a visual learner, check out our assembly videos! They're pretty great!

You Tube Visit: youtube.com/c/SkywalkerTrampolines


STEP 1

Register your Volleyball Game. For info on **warranty registration**, see page 2.

STEP 2




Insert the lower upright pole (2) into the upper upright pole (1).




ASSEMBLY

STEP 3



9 Lug Bolt (x10)




10 M6 Washer (x20)




11 M6 Locknut (x10)

Attach four lug bolts **(9)**, eight M6 washers **(10)**, and four M6 locknuts **(11)** to the side of the upper upright pole **(1)** and the lower upright pole **(2)**. **Make sure all four lug bolts face the same direction.** Then attach one lug bolt, two M6 washers, and one M6 locknut to the other side of the upper upright pole. **Repeat to attach the remaining lug bolt to the upright pole.**




STEP 4




3 Volleyball Net (x1)

Attach the volleyball net **(3)** to the upper upright pole **(1)** at the height you'd like using the Metal clips **(7)**.

Then, attach the opposite end of the volleyball net to another upright pole with two Metal clips **(7)**. Stretch out the volleyball net away from the upright pole until the volleyball net is tight.




STEP 5



4 Upright Ground Stake (x2)

Push the upright ground stake **(4)** into the ground. Make sure the net is pulled tight. Attach the the upright ground stake to the lower upright pole **(2)**.



STEP 6




5 Tensioning Device (x1)



8 Guide Line Cords (x3)


Tie the ends of the three guide line cords **(8)** to the upper upright pole **(1)** and pull to secure the upright pole.

Thread the opposite end of one guide line through the 3 first holes of one tensioning device **(5)**.



ASSEMBLY



STEP 7




5 Tensioning Device (x5) **6** Ground Stake (x6)

After the 3rd hole, thread the line through the eyelet on the ground stake **(5)**, then through the 4th hole, and then tie a knot to secure. Place the ground stake into the ground and pull the line tight.

Now repeat steps 6-7 to secure the remaining five guide line cords.




STEP 8



13 Bag (x1) **16** Plastic Straps (x2)

This bag **(13)** is convenient for you to carry the game when you are playing outdoors.

Please tie the two Upright Ground Stakes with the plastic straps **(16)** as shown. Then put them into the bag.



LIMITED WARRANTY

Skywalker Holdings, LLC warrants its products to be free from defects in material and workmanship under normal use and service conditions. **The steel frame is warranted for three (3) years after the date of purchase. All other parts are warranted for one (1) year after the date of purchase.** Warranty coverage extends only to the original retail purchaser from the date of original purchase. This warranty is only valid concerning products used for residential use. Products used for commercial use, such as schools and daycares, will not be covered.

WHAT IS NOT COVERED?



Weather Damage: The warranty does not cover damage due to the effects or acts of nature, such as earthquakes, wind, hurricanes, tornadoes, lightening, rain, fire, snow, excessive heat and cold conditions and/or sun damage. During the winter months the soft materials will need to be removed and stored in a dry place out of the snow. If left unprotected in the winter months, some components may become damaged, voiding this warranty.



Fading and Rust: Our products are fully galvanized and/or powder-coated. We do not warrant against rust or corrosion. Some areas may have higher air salt content, higher humidity, heavier rain and heavier snow. We do not warrant against fading. We suggests customers use a UV protectant to extend the life of the product.



Loss or damage to Product: caused by shipping, abuse, misuse, improper/abnormal usage or unauthorized repairs are not covered by this warranty and may also void the warranty.



Unauthorized Replacement Parts: The warranty will become void if any defects or damages are associated with the use of unauthorized replacement parts. All replacement parts must be obtained from an authorized retailer.



Assembly Service: The warranty does not cover acts or omissions provided by a third-party assembly service. It is the customer's responsibility to check all boxes and confirm all components are included and in their proper condition before installation occurs.

INSPECTION AND REPLACEMENT PARTS:

1. Your product should be inspected upon unpacking and set up and thereafter on a regular basis. Worn, damaged or broken parts should be replaced immediately and before each use.
2. Call the Skywalker Holdings Customer Service Department at 1-866-603-5867 to file a warranty claim. Be prepared to provide the following information: name, shipping address, a copy of your original sales receipt, a brief description of the problem and cause, product model number and serial number. We may also ask for photos of the damaged/defective parts.
3. Customer service will review your claim and contact you with further instruction.

NOTE: All requested information must be provided in order to review your warranty claim.

To order replacement parts for your product please visit www.skywalkertrampolines.com

Skywalker Holdings, LLC, PO Box 574, Brigham City, UT 84302 USA.

Printed in China © 2019 Skywalker Holdings, LLC

NOTE: Skywalker Holdings, LLC is not responsible or liable for indirect, special or consequential damages arising out of or in connection with the use or performance of the product or other damages with respect to any economic loss, loss of property, loss of revenue or profits, loss of enjoyment or use, cost of removal, installation or other consequential damages. Some states do not allow the exclusion or limitation of incidental or consequential damages. Accordingly, the above limitation may not apply to you.

The warranty extended hereunder is in lieu of all other warranties and any implied warranty of merchantability or fitness for a particular purpose is limited in its scope and duration to the terms set forth herein. Some states or countries do not allow limitations on how long an implied warranty lasts. Accordingly, the above limitation may not apply to you. This warranty gives you specific legal rights. You may also have other rights which vary state to state or country to country.

This warranty is valid only in the country the product was purchased.