

Footwear Size Charts

MENS								
	SIZES							
US	7	8	9	10	11	12	13	14
UK	6.0	7.0	8.0	9.0	10.0	11.0	12.0	13.5
EUR	39.5	40.5	42.0	43.0	44.5	46.0	47.0	48.5
CM	25.9	26.7	27.5	28.3	29.1	29.9	30.7	32.5
INCHES	10.2	10.5	10.8	11.1	11.5	11.8	12.1	13.0

WOMENS								
	SIZES							
US	5	6	7	8	9	10	11	12
UK	2.5	3.5	4.5	5.5	6.5	7.5	8.5	9.5
EUR	35.0	36.0	37.5	38.5	39.5	40.5	42.0	43.0
CM	23.0	23.9	24.6	25.5	26.4	27.2		
INCHES	9.1	9.4	9.7	10.0	10.4	10.7		

Little Kids						
US	11	12	13	1	2	3
UK	10	11	12	13	1	2
EUR	29	30	31	32	33.5	34
CM	18.6	19.2	20.1	20.9	21.7	22.6
INCHES	7.3	7.6	7.9	8.2	8.5	8.9

Big Kids			
US	4	5	6
UK	3	4	5
EUR	36	37	38
CM	23.4	24.3	25.1
INCHES	9.2	9.6	9.9

INFANTS			
US	5	6	7
UK	4	5	6
EUR	21	22	23
CM	12	13	14
INCHES	4.8	5.2	5.6

8	9	10
7	8	9
24	25	27
15	15.5	16.5
6.0	6.2	6.6