

WONDERFO/D
— WAGON —

www.WonderFoldWagon.com

WONDERFO/D
— WAGON —

W1

Assembly & Safety Instructions



Please keep this booklet in a safe place for the life of your WonderFold stroller.
www.WonderFoldWagon.com

⚠ WARNING ⚠

Important—Keep these instructions for future reference.

Avoid Serious Injury To Children From Falling Or Sliding Out:

- Always use harness to restrain each child.
- Never leave children unattended.
- Always set parking brake while loading and unloading children.
- This stroller unit is not for children under 6 months.

Avoid Serious Injury To Children:

- Use with caution when pushing stroller near traffic or in highly congested areas.
- DO NOT use stroller on stairs or escalators with children in it.
- To avoid injury, ensure that your child is kept away when unfolding and folding this product.
- Do not let your child play with this product.
- This product is not suitable for running or skating.

Avoid Injury From Stroller Tipping Over:

- DO NOT carry more than two (2) children.
- DO NOT exceed per seat limit: 33 lbs
- DO NOT place any child taller than 40 inches per seat in this stroller.
- DO NOT allow children to climb into stroller unassisted, or to play or hang onto stroller.

- DO NOT overload stroller as it can become unstable.
- DO NOT add package carrying accessories or hang items from stroller. Parcels or accessories which are not approved by the manufacture placed on the unit may cause the unit to become unstable.

- DO NOT place more than 6.6 lbs. (3 kg) in each storage pocket.

- ALWAYS distribute weight as evenly as possible on each side of the stroller.

Avoid Loss Of Control Of Stroller:

- Ensure that all the locking devices are engaged before use.
 - NEVER leave stroller unattended on a hill or incline even when parking brake is set.
 - Use with caution when pushing stroller on uneven terrain or slopes.
 - ALWAYS set parking brake when the stroller is stationary.
- Avoid Pinch Injury:**
- Keep fingers clear of hinged joints when folding and unfolding the stroller.
 - When making adjustments, always ensure all children are kept well away from any moving parts.

See instructions for additional warnings and use all information.

If any parts are either missing or broken or need for immediate assistance in assembling your stroller, please contact your local dealer or retailer.

Parts Check List.....	3
Assembly	
Unfolding the stroller/Assembly of front wheel/Assembly of rear wheel.....	4
Assembly of Rear Wheels/Assembly of Handle Bar/Canopy Assembly.....	5
Handle Strap Assembly.....	6
Operation	
Securing the Harness.....	6
Parking Brake Operation/Folding the Stroller.....	7
Adjustable handle/Canopy Storage.....	8
Care Safety	
Cleaning.....	8
Replacement Parts List.....	9


Parts Check List

 1. Stroller Body	 2. Rear Wheels	 3. Front Wheels	 4. Canopy SET
 5. Handle Bar with Screws	 6. Brake Bar Set	 7. C-Shape Buckle (located on the brake bar)	 8 O d i o u e i s t e d (located on the front of the stroller)

Assembly

Unfolding the Stroller

1. Stand with hands on front and rear frame tube, and unfold the stroller frame to front and rear position.
2. Stretch out the fabric flaps to both sides of the hand rails to cover the joint on both sides.



1



2

Assembly of Front Wheels

1. Insert front wheels into front wheel housing.
2. Front wheel assembly completed. Pull the front wheel to be certain that wheels are securely locked in place.



1



2

Assembly of Rear Wheels

1. Insert the wheel axle in the brake assembly as picture 1.
2. Insert the buckle into the rear wheel housing as picture 2.
Pull the rear wheel axle to make certain that rear wheel assembly is secure.



1



2

Assembly of Rear Wheels

1. Connect the rear wheel to the rear tube joint.
2. Check the clips are in place on both sides of the wheel housing.



1




2

Assembly of Handle Bar

1. Screw the handle bar tube to the adjust joint using screws.
2. Tighten the screws on both sides.




1



2

Canopy Assembly

1. Connect the canopy tube to the rail on four corners.
2. Assembly of canopy is finished.




1



2

Handle Strap Assembly


1. Take out the handle strap from front pocket of the frame.
2. Fix the handle strap onto the front connecting tube.
3. Use as shown in picture 3.



Operation


Securing the Harness

1. With harness unbuckled, place child in seat.
2. Secure child with harness by placing shoulder and waist belts over shoulders and over thighs. Snap buckle tongues into crotch strap buckle.
3. Snugly adjust each strap by pulling on the free end of the strap and moving the slide adjuster along strap.




Parking Brake Operation

1. Step down on the parking brake pedal to lock. Test the brake to ensure it's locked by trying to push the stroller.
2. Push the parking brake pedal upwards with your foot to release it.




Folding the Stroller

1. Stand in front of the stroller, release the latch on the right hand side.
2. Grasp the folding hinge on both sides.
3. Pull the folding hinge with both hands until the stroller is completely folded.
4. Fix the folding latch in place.




Adjustable Handle

1. Press the adjustable handle button on both sides simultaneously.
2. Move handle up or down to desired height.



Canopy Storage

1. Roll up the canopy fabric.
2. Adjust the handle bar to upright position.
3. Hang the canopy tube onto the handle-bar and insert one end of the canopy tube into the pocket in the storage basket.
4. Secure the strap on the rear tube with the buckle.



Cleaning

Cleaning Stroller

1. Wash stroller frame with mild soap and water.
2. Rinse and wipe or air-dry.

Cleaning Seat Pad

1. Spot clean with mild soap and water.
2. Rinse and wipe or air-dry.

Replacement Parts List

			
1. REAR WHEEL ASSEMBLY	2. FRONT WHEEL ASSEMBLY	3. CANOPY	5. STROLLER JACKET
			
6. HANDLE TUBE	7. BRAKE ASSEMBLY	8. C-SHAPE U-TICK RELEASE BUCKLE	4. HANDLE STRAP

WARNING

Avoid Serious Injury To Children From Falling Or Sliding Out:

- Snugly adjust harness to restrain each child.
- NEVER leave children unattended.
- ALWAYS set parking brake while loading and unloading children.
- DO NOT allow children to climb on stroller or stand on the seat.

One Year Limited Warranty

WonderFold warrants this product to be free from defects in material or workmanship for a period of one year from the date of purchase when used by the original owner according to the manufacturer's instructions.

The warranty does not apply to damage caused by product alteration, or customer/user misuse or abuse of the product. Your sales receipt is your only record of the date of purchase. Please contact WonderFold if you have any warranty questions or if you need replacement parts:

WONDERFOLD
PO BOX 2144
Temple City, CA 91780
hello@WonderFoldWagon.com
1(888) 681-1526