


ASSEMBLY, MAINTENANCE, & **USER MANUAL**

MODEL #SAK160.1



WARNING

Read all precautions and instructions in this manual before using this equipment. Save this manual for future reference. User weight limit 275 lbs.

SKYWALKER

TRAMPOLINES
Skywalker Holdings LLC
P.O. Box 574, Brigham City, UT 84302

TABLE OF CONTENTS

| | |
|---|------|
| Part List..... | 3 |
| Part Identification..... | 4-5 |
| Exploded Drawing-Basketball hoop..... | 5 |
| Exploded Drawing-Ladder & Wind stake..... | 6 |
| Assembly..... | 7-11 |
| Limited Warranty..... | 12 |



STOP EVERYTHING YOU'RE DOING AND REGISTER YOUR PRODUCT

Find our warranty registration online by typing in: www.skywalkertrampolines.com/registration/

You'll need to have the following information handy:

- Name
- Address
- Phone number
- Date of purchase
- Email address
- Model number
- Serial number
- Retailer the product was purchased from

BEFORE YOU BEGIN

Thanks for choosing Skywalker Trampolines! We're just as excited as you are to help your family live an active (but most importantly **FUN**) lifestyle. This model is one of our favorites, and we're confident you'll love it too. To make things easier for you, we've listed important information that you (and your little outdoor adventurers) need to know. Make sure you brush up on the warnings, instructions, assembly, maintenance, and use of your new product because there will be a pop quiz at the end (Okay, not **REALLY**, but if you're still reading this, props to you! You're awesome).



WARNING

Ladders allow young children to climb onto the trampoline. Trampolines are not for children under 6 years of age. Do not use ladder if children under 6 are nearby. Remove ladder when trampoline is not in use, to prevent unauthorized use.



WARNING

Properly secure the trampoline when not in use. Protect it against unauthorized use. If a trampoline ladder is used, the supervisor should remove it from the trampoline when leaving the area to prevent unsupervised access by children under 6 years of age.



IMPORTANT

Trampoline/enclosures and game attachments are susceptible to winds.



WARNING

CHOKING HAZARD- Small parts not for children under 3 years.



WARNING

Adult assembly required.

PART LIST

| Key No. | Qty. | Description |
|---------|------|---------------------|
| 1 | 2 | Curved Ladder Rails |
| 2 | 2 | Ladder Step |
| 3 | 4 | M6x40mm Bolt |
| 4 | 2 | M6x33mm Bolt |
| 5 | 4 | M6 Washer |
| 6 | 6 | M6 Nut |
| 7 | 1 | Lower Frame Base |
| 8 | 1 | Backboard |
| 9 | 1 | Rim with net |
| 10 | 2 | Cinch with cord |
| 11 | 1 | Basketball |
| 12 | 2 | Plastic strip |
| 13 | 4 | Wind stake |
| 14 | 1 | Screw Driver |
| 15 | 1 | Wrench |

ORDERING REPLACEMENT PARTS

We get it, sometimes things happen, but the fun shouldn't stop just because you need a new bolt or screw. To order replacement parts, check out our website www.skywalkertrampolines.com or call our toll-free Customer Care Hotline at **1-866-603-Jump (5867)**, Monday - Thursday 8 a.m. to 5 p.m., Friday 8 a.m. to 3 p.m. (excluding holidays).


Our customer service team will ask you a few questions to get the replacement part sent out as soon as possible. We're not trying to complicate your life, we promise.

When calling, make sure to have the following information ready:


- The model # of the product (see the front cover of this manual)
- The key # and description of the part (see the part list above)
- The quantity needed (only you know the answer to that one!)

PART IDENTIFICATION


Before you begin, take a look at the drawings below to make sure you have all the parts. The numbers in the squares to the left (key numbers) will help you identify the parts during assembly.




1 Curved Ladder Rails **(x2)**




2 Ladder Step **(x2)**




3 M6x40mm Bolt **(x4)**




4 M6x33mm Bolt **(x2)**




5 M6 Washer **(x4)**




6 M6 Nut **(x6)**



7 Lower Frame Base **(x1)**



8 Backboard **(x1)**



9 Rim with net **(x1)**



10 Cinch with cord **(x2)**






11 Basketball **(x1)**




12 Pastic strip **(x2)**


PART IDENTIFICATION



EXPLODED DRAWING - Basketball hoop



EXPLODED DRAWING - Ladder & Wind stake




ASSEMBLY - Ladder

STEP 1




1 Curved Ladder Rails (x2)




2 Ladder Step (x1)


Lay the two curved ladder rails **(1)** on a clear area. Place one of the ladder steps **(2)** onto the bottom of each ladder rail. Slide the step up until the top bolt holes of the rail and step line up. (Make sure the checkered pattern of the step is facing up.)



STEP 2





3 M6x40mm Bolt (x2)




6 M6 Nut (x2)

Insert the M6x40 mm bolt **(3)** through the ladder step and ladder rail. Tighten an M6 nut **(6)** on the back of each bolt.




ASSEMBLY - Ladder


STEP 3



2 Ladder Step (x1)





3 M6x40mm Bolt (x2)




6 M6 Nut (x2)


Repeat steps 1 & 2 to assemble the second ladder step.



STEP 4




7 Lower Frame Base (x1)



4 M6x33 Bolt (x2)





5 M6 Washer (x4)



6 M6 Nut (x2)

With the assembled top portion of the ladder, place the lower frame base (7) onto the ladder rails making sure to align the bolt holes. Insert the M6x33 mm bolt (4) with a M6 washer (5) on either side of the frame. Secure with an M6 nut (6) on each side.




ASSEMBLY - Basketball hoop

STEP 5


Assure that all bolts and end caps are tight and secure.

To place the ladder on the trampoline, simply lift the spring pad and hook the top of the ladder to the trampoline frame.

The assembly of your trampoline accessory ladder is now complete. Enjoy!




STEP 6



8

Backboard (x1)



9

Rim with net (x1)




12



Plastic Strip (x2)

Begin by inserting the Plastic strips **(12)** into the sleeves on back of the Backboard **(8)**.

Then attach the Rim **(9)** to the backboard **(8)** with the provided velcro.




Please note don't attach rim on this small area



ASSEMBLY - Basketball hoop

STEP 7

Next, place the velcro strips on top and bottom of the rim **(9)** on both sides to secure in place.




STEP 8



10 Cinch with cord (x2)


Then, attach the cinch with cord **(10)** to the back corners of the backboard. Push in the end of the cinch to open the hole in the middle, thread the cord through, and pull the cord to make it tight.



STEP 9

Using a ladder, place each end of cords **(10)** onto two pole caps. Push in the end of the cinch and pull the cord to make it tight.

Note: You may have to pull the velcro and fasten it to the rim more tightly in order to make the basketball hoop hang upright.




STEP 10




13 Wind stakes (x4)

To place the wind stakes **(13)**, set one over the top of the trampoline leg where it sits on the ground. The wind stake should straddle the trampoline leg with the points facing down. Push or pound the wind stake firmly into the ground. Take care that they do not create a tripping hazard. All four wind stakes should be used for best results.



STEP 11

Congratulations on setting up your new accessory kit! So here comes the real question... are you satisfied with this product? If you are, go ahead and write a review on the retailer's site you bought it from. We'd really appreciate it... and if we could, we'd give you a gold star. Are you completely frustrated and have some choice words for us? Contact us directly! We're not trying to ruin your life, we promise. And we'll do everything we can to make it right again. See contact info on page 2-3.



LIMITED WARRANTY

Skywalker Holdings, LLC warrants its products to be free from defects in material and workmanship under normal use and service conditions. **The steel frame is warranted for three (3) years after the date of purchase. All other parts are warranted for one (1) year after the date of purchase.** Warranty coverage extends only to the original retail purchaser from the date of original purchase. This warranty is only valid concerning products used for residential use. Products used for commercial use, such as schools and daycares, will not be covered.

WHAT IS NOT COVERED?



Weather Damage: The warranty does not cover damage due to the effects or acts of nature, such as earthquakes, wind, hurricanes, tornadoes, lightening, rain, fire, snow, excessive heat and cold conditions and/or sun damage. During the winter months the soft materials will need to be removed and stored in a dry place out of the snow. If left unprotected in the winter months, some components may become damaged, voiding this warranty.



Fading and Rust: Our products are fully galvanized and/or powder-coated. We do not warrant against rust or corrosion. Some areas may have higher air salt content, higher humidity, heavier rain and heavier snow. We do not warrant against fading. We suggests customers use a UV protectant to extend the life of the product.



Loss or damage to Product Due to: caused by shipping, abuse, misuse, improper/abnormal usage or unauthorized repairs are not covered by this warranty and may also void the warranty.



Unauthorized Replacement Parts: he warranty will become void if any defects or damages are associated with the use of unauthorized replacement parts. All replacement parts must be obtained from an authorized retailer.



Assembly Service: The warranty does not cover acts or omissions provided by a third-party assembly service. It is the customer's responsibility to check all boxes and confirm all components are included and in their proper condition before installation occurs.

INSPECTION AND REPLACEMENT PARTS:

1. Your product should be inspected upon unpacking and set up and thereafter on a regular basis. Worn, damaged or broken parts should be replaced immediately and before each use.
2. Call the Skywalker Holdings Customer Service Department at 1-866-603-5867 to file a warranty claim. Be prepared to provide the following information: name, shipping address, a copy of your original sales receipt, a brief description of the problem and cause, product model number and serial number. We may also ask for photos of the damaged/defective parts.
3. Customer service will review your claim and contact you with further instruction.

NOTE: All requested information must be provided in order to review your warranty claim.

To order replacement parts for your product please visit www.skywalkertrampolines.com

Skywalker Holdings, LLC, PO Box 574, Brigham City, UT 84302 USA.

Printed in China © 2020 Skywalker Holdings, LLC

NOTE: Skywalker Holdings, LLC is not responsible or liable for indirect, special or consequential damages arising out of or in connection with the use or performance of the product or other damages with respect to any economic loss, loss of property, loss of revenue or profits, loss of enjoyment or use, cost of removal, installation or other consequential damages. Some states do not allow the exclusion or limitation of incidental or consequential damages. Accordingly, the above limitation may not apply to you.

The warranty extended hereunder is in lieu of all other warranties and any implied warranty of merchantability or fitness for a particular purpose is limited in its scope and duration to the terms set forth herein. Some states or countries do not allow limitations on how long an implied warranty lasts. Accordingly, the above limitation may not apply to you. This warranty gives you specific legal rights. You may also have other rights which vary state to state or country to country.

This warranty is valid only in the country the product was purchased.